## 1970-71 DODGE & PLYMOUTH B-BODY DASH HARNESS

## \*\*\*CAUTION\*\*\*

This dash harness is manufactured with connections for the DODGE CHARGER concealed headlamp door system.

If you are <u>NOT</u> installing this harness in a DODGE CHARGER, the connections for the concealed headlamp door system will need the bare terminals to be insulated with shrink tube or good quality electrical tape, then tie strapped or spot taped up to the harness main body to avoid damage and protect them from abrasion with sharp metal underneath the dash area.

PLEASE DO NOT cut the wires; cutting these wires will cause ignition & headlamp lighting circuits to fail.

ELECTRIC FABRICATORS, INC AUTOMOTIVE WIRING SYSTEMS (562) 926-9552 www.wiringharness.com	
	SHEET NO.
04-04-20	TOFT
INSTRUCTION SHEET: 1970-71 DODGE & PLYMOUTH B-BODY DASH HARNESS CAUTION	
92973397	