



**INSTALLATION INSTRUCTIONS FOR LATE 1968 & 1969 CHRYSLER
BACK-UP LAMP SWITCH HARNESS, WITH MANUAL TRANS**

NOTE: INSTALL TERMINALS INTO CORRECT CAVITY OF CONNECTORS (SEE DRAWING) MAINTAINING PROPER ORIENTATION.

REVISION DATE

9-18-90

M&H PART #

01075

PART #

92963181