



M&H ELECTRIC FABRICATORS, INC.
 13537 Alondra Blvd. Santa Fe Springs, CA 90670
 Phone (562) 928-6572 Fax (562) 928-6572

INSTRUCTION SET 92963723 # 35825 REV 1.1 8/1/95

©2001 M&H Electric Fabricators, Inc. All rights reserved.
 The design and documents included in this assembly are the exclusive property of M&H Electric Fabricators, Inc. No part of the design or documentation may be reproduced without the express permission of M&H Electric Fabricators, Inc.

92963723

WIRE USAGE CHART

92963723

<u>WIRE</u>	<u>WIRE COLOR</u>	<u>GA.</u>	<u>CIRCUIT DESCRIPTION</u>
1	black	10	Starter "BAT" terminal to ignition switch "BAT" terminal
2	dk blue	12	Neutral safety switch to ignition switch "SOL" terminal
3	dk green	18	Ignition switch to coil "+" terminal
3	dk green	18	Ignition switch to ballast resistor
4	dk blue	18	Oil pressure sender to oil pressure indicator light
5	brown	18	Ignition switch to ballast resistor
5	brown	18	Ignition switch to oil pressure indicator light
6	purple	12	Starter "SOL" terminal to neutral safety switch
7	dk green	18	Temperature sender to temperature gauge terminal