



M&H ELECTRIC
FABRICATORS, INC.

13537 Alondra Blvd. Santa Fe Springs CA 90670
Phone (562) 928-9552 Fax (562) 928-9572

INSTRUCTION SET 92963733 # 35835 REV 1.1 8/1/95

The design and documents included in this assembly are the exclusive property of M&H Electric Fabricators, Inc. No part of the M&H design or documentation may be reproduced without the express permission of M&H Electric Fabricators, Inc.

92963733

WIRE USAGE CHART

92963733

<u>WIRE</u>	<u>WIRE COLOR</u>	<u>GA.</u>	<u>CIRCUIT DESCRIPTION</u>
1	black	10	Starter "BAT" terminal to ignition switch "BAT" terminal
6a	purple	12	Neutral safety switch to fuel meter solenoid
7	purple	12	Starter "SOL" terminal to neutral safety switch
6b	black	12	Fuel meter solenoid terminal to ignition switch
13	brown	18	Electric choke terminal to ballast resistor
2	dk blue	18	Oil pressure sender to oil pressure indicator light
3a	dk green	18	Coil "+" terminal to ballast resistor
3b	dk green	18	Starter "RES" terminal to ballast resistor
4	dk green	16	Temperature sender to temperature gauge terminal
5a	tan	18	Ignition switch to ballast resistor
5b	tan	18	Ignition switch to oil pressure indicator light