



M&H ELECTRIC
FABRICATORS, INC.

13537 Alameda Blvd. Santa Fe Springs CA 90670
Phone (562) 928-6652 Fax (562) 928-6572

INSTRUCTION SET 92963718 # 35820 REV 1.1 8/1/95

The design and documents included in this assembly are the exclusive property of M&H Electric Fabricators, Inc. No part of the design or documentation may be reproduced without the express permission of M&H Electric Fabricators, Inc.

92963718

WIRE USAGE CHART

92963718

<u>WIRE</u>	<u>WIRE COLOR</u>	<u>GA.</u>	<u>CIRCUIT DESCRIPTION</u>
1	black	10	Starter "BAT" terminal to ignition switch "BAT" terminal
2	purple	12	Starter "SOL" terminal to ignition switch "SOL" terminal
3a	dk green	18	Coll "+" terminal to ignition switch
3b	dk green	18	Ignition switch to ballast resistor
4a	brown	18	Ignition switch to ballast resistor
4b	brown	18	Ignition switch to oil pressure light
5	dk blue	18	Oil pressure sender to oil pressure indicator light