



M&H ELECTRIC FABRICATORS, INC.

13537 Alondra Blvd. Santa Fe Springs CA 90670
 Phone (562) 928-6002 Fax (562) 928-9572

INSTRUCTION SET 92963724 # 35826 REV 1.1 8/1/95

©2001
 M&H Electric Fabricators, Inc.
 All rights reserved

The design and documents included in this assembly are the exclusive property of M&H Electric Fabricators, Inc. No part of this design or documentation may be reproduced without the express permission of M&H Electric Fabricators, Inc.

92963724

WIRE USAGE CHART

92963724

<u>WIRE</u>	<u>WIRE COLOR</u>	<u>GA.</u>	<u>CIRCUIT DESCRIPTION</u>
1	black	10	Starter "BAT" terminal to ignition switch "BAT" terminal
6	purple	12	Starter "SOL" terminal to ignition switch "SOL" terminal
5a	brown	18	Ignition switch to ballast resistor
5b	brown	18	Ignition switch to oil pressure indicator light
4	dk blue	18	Oil pressure sender to oil pressure indicator light
3a	dk green	18	Ignition switch to coil "+" terminal
3b	dk green	18	Ignition switch to ballast resistor
7	dk green	18	Temperature sender to temperature gauge terminal