



1. ROUTE TERMINAL AND WIRE THROUGH HOLE IN GLOVE BOX FRAME.
2. POSITION THE WIRE AND GLOVE BOX LIGHT SOCKET AS SHOWN BELOW.
3. INSERT TERMINAL INTO GLOVE BOX LIGHT SOCKET WITH THE WIRE CRIMP UP TOWARD THE OUTSIDE EDGE OF THE LIGHT SOCKET BODY.



4. INSERT A BULB INTO THE LIGHT SOCKET AND PULL THE ASSEMBLY FORWARD TO LOCK INTO THE HOLE IN THE GLOVE BOX SHEET METAL FRAME.
5. PLUG THE OTHER END OF THE WIRE INTO AN AVAILABLE POWER TERMINAL ON THE FUSE PANEL.
6. AN OPTIONAL IN-LINE CONNECTOR IS SUPPLIED TO TAP INTO AN EXISTING POWER WIRE.

 M&H Electric Fabricators, Inc. <small>AUTOMOTIVE WIRING SYSTEMS</small>	
Phone (562) 928-9552 Fax (562) 928-9572	
TITLE	INSTRUCTION SHEET GLOVE BOX LIGHT HARNESS 1956-57 CHEVROLET
DWG NO.	92963417

1. ROUTE TERMINAL AND WIRE THROUGH HOLE IN GLOVE BOX FRAME.
2. POSITION THE WIRE AND GLOVE BOX LIGHT SOCKET AS SHOWN BELOW.
3. INSERT TERMINAL INTO GLOVE BOX LIGHT SOCKET WITH THE WIRE CRIMP UP TOWARD THE OUTSIDE EDGE OF THE LIGHT SOCKET BODY.



4. INSERT A BULB INTO THE LIGHT SOCKET AND PULL THE ASSEMBLY FORWARD TO LOCK INTO THE HOLE IN THE GLOVE BOX SHEET METAL FRAME.
5. PLUG THE OTHER END OF THE WIRE INTO AN AVAILABLE POWER TERMINAL ON THE FUSE PANEL.
6. AN OPTIONAL IN-LINE CONNECTOR IS SUPPLIED TO TAP INTO AN EXISTING POWER WIRE.

 M&H Electric Fabricators, Inc. <small>AUTOMOTIVE WIRING SYSTEMS</small>	
Phone (562) 928-9552 Fax (562) 928-9572	
TITLE	INSTRUCTION SHEET GLOVE BOX LIGHT HARNESS 1956-57 CHEVROLET
DWG NO.	92963417