

1. Plug the harness into the mating connector at the base of the steering column.
2. Plug the other end of the harness into the mating connector on your dash harness.
3. Connect the Dark Green wire to the horn button lead.
4. Plug the red wire to a battery power source on the fuse panel. An auxiliary battery source at the back of the cigarette lighter may also be used by first removing the existing heavy red wire and plugging it into the red pigtail wire.
5. Install a heavy duty 2 prong flasher into the "V" shaped plastic connector to enable use of the 4 way flashers.
6. Install a 10 amp fuse into the in line fuse holder.

M&H Electric Fabricators, Inc.

AUTOMOTIVE WIRING SYSTEMS

Phone (562) 926-9552


Fax (562) 926-9572

TITLE

INSTRUCTION SHEET
STEERING COLUMN
ADAPTER HARNESS

DWG NO.

92963630



1. Plug the harness into the mating connector at the base of the steering column.
2. Plug the other end of the harness into the mating connector on your dash harness.
3. Connect the Dark Green wire to the horn button lead.
4. Plug the red wire to a battery power source on the fuse panel. An auxiliary battery source at the back of the cigarette lighter may also be used by first removing the existing heavy red wire and plugging it into the red pigtail wire.
5. Install a heavy duty 2 prong flasher into the "V" shaped plastic connector to enable use of the 4 way flashers.
6. Install a 10 amp fuse into the in line fuse holder.

M&H Electric Fabricators, Inc.

AUTOMOTIVE WIRING SYSTEMS

Phone (562) 926-9552

Fax (562) 926-9572

TITLE

INSTRUCTION SHEET
STEERING COLUMN
ADAPTER HARNESS

DWG NO.

92963630